



SW-MOTECH
BAGS-CONNECTION



TRIUMPH
Selection

TRIUMPH

Daytona 675



- 1 QUICK-LOCK EVO Tankring. Schwarz. QUICK-LOCK EVO Tankring. Black. 06 – 11 ☎ TRT.00.640.16000/B
QUICK-LOCK EVO Micro. Schwarz. QUICK-LOCK EVO Micro. Black. 06 – 11 ☎ BC.TRS.00.110.20000
QUICK-LOCK EVO Daypack. Schwarz. QUICK-LOCK EVO Daypack. Black. 06 – 11 ☎ BC.TRS.00.108.20000
QUICK-LOCK EVO Sport. Schwarz. QUICK-LOCK EVO Sport. Black. 06 – 11 ☎ BC.TRS.00.101.20000
QUICK-LOCK EVO Elektrik Micro. Schwarz. QUICK-LOCK EVO Electric Micro. Black. 06 – 11 ☎ BC.TRE.00.110.20000
QUICK-LOCK EVO Elektrik Daypack. Schwarz. QUICK-LOCK EVO Electric Daypack. Black. 06 – 11 ☎ BC.TRE.00.108.20000
QUICK-LOCK EVO Elektrik Sport. Schwarz. QUICK-LOCK EVO Electric Sport. Black. 06 – 11 ☎ BC.TRE.00.101.20000
- 2 BLAZE® H Satteltaschen-Set. Schwarz. BLAZE® H Panniers Set. Black. 06 – 11 ☎ BC.HTA.11.740.10400/B
- 3 Hecktasche Slipstream. Schwarz. Tailbag Slipstream. Black. 06 – 11 ☎ BC.HTA.00.307.10000
Hecktasche Rearbag. Schwarz. Tailbag Rearbag. Black. 06 – 11 ☎ BC.HTA.00.304.10000
Hecktasche Cargobag. Schwarz. Tailbag Cargobag. Black. 06 – 11 ☎ BC.HTA.00.306.10000
Hecktasche Speedpack®. Schwarz. Tailbag Speedpack®. Black. 06 – 11 ☎ BC.HTA.00.301.10000
Hecktasche Drybag M. Gelb. Tailbag Drybag M. Yellow. 06 – 11 ☎ BCK.HTA.00.053.100/Y
Hecktasche Drybag M. Schwarz. Tailbag Drybag M. Black. 06 – 11 ☎ BC.WPB.00.001.10000
- 4 Spiegelverlängerung. Schwarz. Kontur-Distanzstück. Mirror Extension. Black. Profile. 05 – 11 + SVL.11.501.10000/B
Kugelklemme 13,5 - 14,7 Ball Clamp 13.5 - 14.7 06 – 11 ☎ CPA.00.424.13000/B
Kugelklemme Universalhalter-Kit 13,5 - 14,7 Ball Clamp Kit 13.5 - 14.7 06 – 11 ☎ CPA.00.424.15000/B



Street Triple / R



Street Triple

- QUICK-LOCK EVO Tankring. Schwarz. QUICK-LOCK EVO Tankring. Black. 07 – ☎ TRT.00.640.16000/B
QUICK-LOCK EVO Micro. Schwarz. QUICK-LOCK EVO Micro. Black. 07 – ☎ BC.TRS.00.110.20000
QUICK-LOCK EVO Daypack. Schwarz. QUICK-LOCK EVO Daypack. Black. 07 – ☎ BC.TRS.00.108.20000
QUICK-LOCK EVO Sport. Schwarz. QUICK-LOCK EVO Sport. Black. 07 – ☎ BC.TRS.00.101.20000
ALU-RACK. Schwarz. ALU-RACK. Black. 07 – 12 ☎ GPT.11.574.15000/B
- 1 ALU-RACK. Schwarz. ALU-RACK. Black. 13 – ☎ GPT.11.283.15000/B
Hecktasche Slipstream. Schwarz. Tailbag Slipstream. Black. 07 – ☎ BC.HTA.00.307.10000
Hecktasche Rearbag. Schwarz. Tailbag Rearbag. Black. 07 – ☎ BC.HTA.00.304.10000
Hecktasche Rackpack. Schwarz. Tailbag Rackpack. Black. 07 – ☎ BC.HTA.00.305.10000
Hecktasche Racepack®. Schwarz. Tailbag Racepack®. Black. 07 – ☎ BC.HTA.00.302.10000
BLAZE® H Satteltaschen-Set. Schwarz. BLAZE® H Panniers Set. Black. 07 – 12 ☎ BC.HTA.11.740.10200/B
BLAZE® Satteltaschen-Set. Schwarz. BLAZE® Panniers Set. Black. 13 – ☎ BC.HTA.11.740.10600/B
- 2 Lenkererhöhung. Silber. h 20 mm. Handlebar Riser. Silver. h 20 mm. 13 – ☎ LEH.11.039.10200/S
Spiegelverlängerung. Schwarz. Lenkerausleger. Mirror Extension. Black. Universal. 07 – + SVL.00.505.101
- 3 QUICK-LOCK GPS-Halter. Schwarz. QUICK-LOCK GPS Mount. Black. 11 – ☎ GPS.11.646.10400/B
Vorderachs-Sturypad-Kit. Schwarz. Front Axle Slider Kit. Black. 13 – ☎ STP.11.176.10500/B
Hinterachs-Sturypad-Kit. Schwarz. Rear Axle Slider Kit. Black. 13 – ☎ STP.11.176.10600/B
Sturypad-Kit. Schwarz. Frame Slider Kit. Black. 07 – 12 ☎ STP.11.590.10100/B
Sturypad-Kit. Schwarz. Frame Slider Kit. Black. 13 – ☎ STP.11.590.10400/B
Schutzbügel. Schwarz. Crashbar. Black. 07 – 12 ☎ SBL.11.431.10000/B
Hauptständer. Schwarz. Centerstand. Black. 07 – 12 + HPS.11.416.10000/B



Street Triple R

- QUICK-LOCK EVO Tankring. Schwarz. QUICK-LOCK EVO Tankring. Black. 08 – 10 ☎ TRT.00.640.16000/B
ALU-RACK. Schwarz. ALU-RACK. Black. 08 – 11 ☎ GPT.11.574.15000/B
Hecktasche Rearbag. Schwarz. Tailbag Rearbag. Black. 08 – ☎ BC.HTA.00.304.10000
Hecktasche Rackpack. Schwarz. Tailbag Rackpack. Black. 08 – ☎ BC.HTA.00.305.10000
Hecktasche Slipstream. Schwarz. Tailbag Slipstream. Black. 08 – ☎ BC.HTA.00.307.10000
BLAZE® H Satteltaschen-Set. Schwarz. BLAZE® H Panniers Set. Black. 08 – 11 ☎ BC.HTA.11.740.10200/B



TRIUMPH

Tiger 800



- QUICK-LOCK EVO Tankring. Schwarz. QUICK-LOCK EVO Tankring. Black. 10 – [TRT.00.640.16000/B](#)
 QUICK-LOCK EVO Micro. Schwarz. QUICK-LOCK EVO Micro. Black. 10 – [BC.TRS.00.110.20000](#)
 QUICK-LOCK EVO Daypack. Schwarz. QUICK-LOCK EVO Daypack. Black. 10 – [BC.TRS.00.108.20000](#)
 1 QUICK-LOCK EVO City. Schwarz. QUICK-LOCK EVO City. Black. 10 – [BC.TRS.00.104.20000](#)
 QUICK-LOCK EVO GS. Schwarz. QUICK-LOCK EVO GS. Black. 10 – [BC.TRS.00.103.20000](#)
 QUICK-LOCK EVO Elektrik Micro. Schwarz. QUICK-LOCK EVO Electric Micro. Black. 10 – [BC.TRE.00.110.20000](#)
 QUICK-LOCK EVO Elektrik Daypack. Schwarz. QUICK-LOCK EVO Electric Daypack. Black. 10 – [BC.TRE.00.108.20000](#)
 QUICK-LOCK EVO Elektrik City. Schwarz. QUICK-LOCK EVO Electric City. Black. 10 – [BC.TRE.00.104.20000](#)
 QUICK-LOCK EVO Elektrik GS. Schwarz. QUICK-LOCK EVO Electric GS. Black. 10 – [BC.TRE.00.103.20000](#)
 2 QUICK-LOCK EVO Kofferträger. Schwarz. QUICK-LOCK EVO Side Carrier. Black. 10 – [KFT.11.748.20000/B](#)
 TraX® EVO Koffersystem. Schwarz. 45/37 l. TraX® EVO Pannier System. Black. 45/37 l. 10 – [KFT.11.748.50000/B](#)
 TraX® EVO Koffersystem. Silber. 45/37 l. TraX® EVO Pannier System. Silver. 45/37 l. 10 – [KFT.11.748.50000/S](#)
 3 AERO ABS-Seitenkoffersystem. Schwarz. AERO ABS Sidecase System. Black. 10 – [KFT.11.748.60000/B](#)
 4 ALU-RACK. Schwarz. ALU-RACK. Black. 10 – [GPT.11.747.15000/B](#)
 STEEL-RACK. Schwarz. STEEL-RACK. Black. 10 – [GPT.11.747.20001/B](#)
 Hecktasche Slipstream. Schwarz. Tailbag Slipstream. Black. 10 – [BC.HTA.00.307.10000](#)
 Hecktasche Jetpack. Schwarz. Tailbag Jetpack. Black. 10 – [BC.HTA.00.303.10000](#)
 Hecktasche Rearbag. Schwarz. Tailbag Rearbag. Black. 10 – [BC.HTA.00.304.10000](#)

- Hecktasche Rackpack. Schwarz. Tailbag Rackpack. Black. 10 – [BC.HTA.00.305.10000](#)
 5 Hecktasche Cargobag. Schwarz. Tailbag Cargobag. Black. 10 – [BC.HTA.00.306.10000](#)
 Hecktasche Speedpack®. Schwarz. Tailbag Speedpack®. Black. 10 – [BC.HTA.00.301.10000](#)
 Hecktasche Drybag M. Anthrazit/Schwarz. Tailbag Drybag M. Anthracite/Black. 10 – [BC.WPB.00.001.10000](#)
 Hecktasche Drybag L. Anthrazit/Schwarz. Tailbag Drybag L. Anthracite/Black. 10 – [BC.WPB.00.002.10000](#)
 Hecktasche Drybag L. Neon-Gelb. Tailbag Drybag L. Neon-Yellow. 10 – [BCK.HTA.00.047.100/Y](#)
 Scheinwerferschutz. Schwarz. Headlight Protection. Black. 10 – [LPS.11.124.10000/B](#)
 Lenkererhöhung. Silber. h 20 mm. Bar Riser. Silver. h 20 mm. 10 – [LEH.11.039.10000/S](#)
 BB STORM Handprotektoren-Kit. Schwarz. BB STORM Handguard Kit. Black. 10 – [HPR.00.220.10500/B](#)
 KOBRA Handprotektoren-Kit. Schwarz. KOBRA Handguard Kit. Black. 10 – [HPR.00.220.20500/B](#)
 Spiegelverlängerung. Schwarz. Lenker ausleger. Mirror Extension. Black. Universal. 10 – [SVL.00.505.101](#)
 Zigarettenanzünder-Befestigungsblech. Cigarette Lighter Outlet Bracket. 10 – [CPA.07.006.18001/B](#)
 QUICK-LOCK GPS-Halter. Schwarz. QUICK-LOCK GPS Mount. Black. 10 – [GPS.11.646.10201/B](#)
 GPS-Kit Cockpit. Schwarz. GPS-Kit Cockpit. Black. 10 – [GPS.11.823.10000/B](#)
 6 HAWK Scheinwerferhalter-Set. Schwarz. HAWK Light Mount Set. Black. 10 – [NSW.11.004.10100/B](#)
 7 HAWK Nebelscheinwerfer-Set. Schwarz. HAWK Fog Light Set. Black. 10 – [NSW.11.004.50100/B](#)
 HAWK Nebelscheinwerfer-Set. Silber. HAWK Fog Light Set. Silver. 10 – [NSW.11.004.50100/S](#)
 Schutzbügel. Schwarz. Crashbar. Black. 10 – [SBL.11.749.10000/B](#)
 Vorderachs-Sturzpadd-Kit. Schwarz. Front Axle Slider Kit. Black. 10 – [STP.11.176.10000/B](#)
 Hinterachs-Sturzpadd-Kit. Schwarz. Rear Axle Slider Kit. Black. 10 – [STP.11.176.10100/B](#)
 Bremsflüssigkeitsbehälterschutz. Silber. Brake Reservoir Guard. Silver. 10 – [SCT.11.174.10000/S](#)
 Kettenschutz. Schwarz. Chain Guard. Black. 10 – [KTS.11.115.10000/B](#)
 Schalthebel. Gear Lever. 10 – [FSC.11.127.10000/B](#)
 Fersenschutz Rechte Seite. Silber. Heel Guard Right Side. Silver. 10 – [SCT.11.174.10100/S](#)
 Fersenschutz Linke Seite. Silber. Heel Guard Left Side. Silver. 10 – [SCT.11.174.10200/S](#)
 Fußrasten-Kit. Silber. Footrest Kit. Silver. 10 – [FRS.11.011.10101/S](#)
 Motorschutz. Schwarz. Engine Guard. Black. 10 – [MSS.11.752.10000/B](#)
 Seitenständerfuß. Silber. Sidestand Foot. Silver. 10 – [STS.11.102.10000/S](#)
 8 Hauptständer. Schwarz. Centerstand. Black. 10 – [HPS.11.753.10000/B](#)



TRIUMPH

Tiger 800 XC



- QUICK-LOCK EVO Tankring. Schwarz. QUICK-LOCK EVO Tankring. Black. 10 – [TRT.00.640.16000/B](#)
 QUICK-LOCK EVO Micro. Schwarz. QUICK-LOCK EVO Micro. Black. 10 – [BC.TRS.00.110.20000](#)
 QUICK-LOCK EVO Daypack. Schwarz. QUICK-LOCK EVO Daypack. Black. 10 – [BC.TRS.00.108.20000](#)
 QUICK-LOCK EVO City. Schwarz. QUICK-LOCK EVO City. Black. 10 – [BC.TRS.00.104.20000](#)
1 QUICK-LOCK EVO GS. Schwarz. QUICK-LOCK EVO GS. Black. 10 – [BC.TRS.00.103.20000](#)
 QUICK-LOCK EVO Elektrik Micro. Schwarz. QUICK-LOCK EVO Electric Micro. Black. 10 – [BC.TRE.00.110.20000](#)
 QUICK-LOCK EVO Elektrik Daypack. Schwarz. QUICK-LOCK EVO Electric Daypack. Black. 10 – [BC.TRE.00.108.20000](#)
 QUICK-LOCK EVO Elektrik City. Schwarz. QUICK-LOCK EVO Electric City. Black. 10 – [BC.TRE.00.104.20000](#)
 QUICK-LOCK EVO Elektrik GS. Schwarz. QUICK-LOCK EVO Electric GS. Black. 10 – [BC.TRE.00.103.20000](#)
 QUICK-LOCK EVO Kofferträger. Schwarz. QUICK-LOCK EVO Side Carrier. Black. 10 – [KFT.11.748.20000/B](#)
 TraX® EVO Koffersystem. Schwarz. 45/37 l. TraX® EVO Pannier System. Black. 45/37 l. 10 – [KFT.11.748.50000/B](#)
 TraX® EVO Koffersystem. Silber. 45/37 l. TraX® EVO Pannier System. Silver. 45/37 l. 10 – [KFT.11.748.50000/S](#)
 AERO ABS-Seitenkoffersystem. Schwarz. AERO ABS Sidecase System. Black. 10 – [KFT.11.748.60000/B](#)
2 ALU-RACK. Schwarz. ALU-RACK. Black. 10 – [GPT.11.747.15000/B](#)
3 STEEL-RACK. Schwarz. STEEL-RACK. Black. 10 – [GPT.11.747.20001/B](#)
 Hecktasche Slipstream. Schwarz. Tailbag Slipstream. Black. 10 – [BC.HTA.00.307.10000](#)
4 Hecktasche Jetpack. Schwarz. Tailbag Jetpack. Black. 10 – [BC.HTA.00.303.10000](#)
 Hecktasche Rearbag. Schwarz. Tailbag Rearbag. Black. 10 – [BC.HTA.00.304.10000](#)



TRIUMPH

Tiger 800 XC

- Hecktasche Rackpack. Schwarz. Tailbag Rackpack. Black. 10 – [BC.HTA.00.305.10000](#)
 Hecktasche Cargobag. Schwarz. Tailbag Cargobag. Black. 10 – [BC.HTA.00.306.10000](#)
 Hecktasche Speedpack®. Schwarz. Tailbag Speedpack®. Black. 10 – [BC.HTA.00.301.10000](#)
 Hecktasche Drybag M. Anthrazit/Schwarz. Tailbag Drybag M. Anthracite/Black. 10 – [BC.WPB.00.001.10000](#)
 Hecktasche Drybag L. Anthrazit/Schwarz. Tailbag Drybag L. Anthracite/Black. 10 – [BC.WPB.00.002.10000](#)
 Hecktasche Drybag L. Neon-Gelb. Tailbag Drybag L. Neon-Yellow. 10 – [BCK.HTA.00.047.100/Y](#)
 Scheinwerferschutz. Schwarz. Headlight Protection. Black. 10 – [LPS.11.124.10000/B](#)
 HAWK Scheinwerferhalter-Set. Schwarz. HAWK Light Mount Set. Black. 10 – [NSW.11.004.10100/B](#)
 HAWK Nebelscheinwerfer-Set. Schwarz. HAWK Fog Light Set. Black. 10 – [NSW.11.004.50100/B](#)
 HAWK Nebelscheinwerfer-Set. Silber. HAWK Fog Light Set. Silver. 10 – [NSW.11.004.50100/S](#)
5 Lenkererhöhung. Silber. h 20 mm. Bar Riser. Silver. h 20 mm. 10 – [LEH.11.039.10000/S](#)
 Spiegelverlängerung. Schwarz. Lenkerausleger. Mirror Extension. Black. Universal. 10 – [SVL.00.505.101](#)
 BB STORM Handprotektoren-Kit. Schwarz. BB STORM Handguard Kit. Black. 10 – [HPR.00.220.10500/B](#)
 KOBRA Handprotektoren-Kit. Schwarz. KOBRA Handguard Kit. Black. 10 – [HPR.00.220.20500/B](#)
 Zigarettanzünder-Befestigungsblech. Cigarette Lighter Outlet Bracket. 10 – [CPA.07.006.18001/B](#)
 QUICK-LOCK GPS-Halter. Schwarz. QUICK-LOCK GPS Mount. Black. 10 – [GPS.11.646.10201/B](#)
 GPS-Kit Cockpit. Schwarz. GPS-Kit Cockpit. Black. 10 – [GPS.11.823.10000/B](#)
 Vorderachs-Sturzpadd-Kit. Schwarz. Front Axle Slider Kit. Black. 10 – [STP.11.176.10000/B](#)
 Hinterachs-Sturzpadd-Kit. Schwarz. Rear Axle Slider Kit. Black. 10 – [STP.11.176.10100/B](#)
6 Schutzbügel. Schwarz. Crashbar. Black. 10 – [SBL.11.749.10000/B](#)
7 Bremsflüssigkeitsbehälterschutz. Silber. Brake Reservoir Guard. Silver. 10 – [SCT.11.174.10000/S](#)
 Kettenschutz. Schwarz. Chain Guard. Black. 10 – [KTS.11.115.10000/B](#)
8 Fersenschutz Rechte Seite. Silber. Heel Guard Right Side. Silver. 10 – [SCT.11.174.10100/S](#)
 Fersenschutz Linke Seite. Silber. Heel Guard Left Side. Silver. 10 – [SCT.11.174.10200/S](#)
 Fußrasten-Kit. Silber. Footrest Kit. Silver. 10 – [FRS.11.011.10101/S](#)
9 Motorschutz. Schwarz. Engine Guard. Black. 10 – [MSS.11.752.10000/B](#)
 Seitenständerfuß. Silber. Sidestand Foot. Silver. 10 – [STS.11.102.10000/S](#)
 Hauptständer. Schwarz. Centerstand. Black. 10 – [HPS.11.751.10000/B](#)



ThruXton 900 / Sprint RS/ST



ThruXton 900

- 1 BLAZE® Satteltaschen-Set. Schwarz. BLAZE® Panniers Set. Black. 04 – [BC.HTA.11.740.10500/B](#)
 Hecktasche Slipstream. Schwarz. Tailbag Slipstream. Black. 04 – [BC.HTA.00.307.10000](#)
 Hecktasche Rearbag. Schwarz. Tailbag Rearbag. Black. 04 – [BC.HTA.00.304.10000](#)
 Hecktasche Cargobag. Schwarz. Tailbag Cargobag. Black. 04 [BC.HTA.00.306.10000](#)
 Hecktasche Racepack®. Schwarz. Tailbag Racepack®. Black. 04 – [BC.HTA.00.302.10000](#)
 Hecktasche Speedpack®. Schwarz. Tailbag Speedpack®. Black. 04 – [BC.HTA.00.301.10000](#)
 Hecktasche Drybag M. Anthrazit/Schwarz. Tailbag Drybag M. Anthracite/Black. 04 – [BC.WPB.00.001.10000](#)
 Hecktasche Drybag M. Neon-Gelb. Tailbag Drybag M. Neon-Yellow. 04 – [BCK.HTA.00.053.100/Y](#)
 Spiegelverlängerung. Schwarz. Lenkerausleger. Mirror Extension. Black. Universal. 04 – 07 [SVL.00.505.101](#)
 HAWK Scheinwerferklemmen-Set. Schwarz. HAWK Light Clamp Set. Black. 04 – [NSW.00.004.13000/B](#)
- 2 Schutzbügel. Schwarz. Crashbar. Black. 04 – [SBL.11.249.10000/B](#)



Sprint RS / Sprint ST

- QUICK-LOCK Kofferträger. Schwarz. QUICK-LOCK Side Carrier. Black. 02 – 04 [KFT.11.267.100](#)
- 3 ALU-RACK. Schwarz. ALU-RACK. Black. 02 – 04 [GPT.11.291.100/B](#)
 Hecktasche Slipstream. Schwarz. Tailbag Slipstream. Black. 02 – 04 [BC.HTA.00.307.10000](#)
 Hecktasche Rearbag. Schwarz. Tailbag Rearbag. Black. 02 – 04 [BC.HTA.00.304.10000](#)
 Hecktasche Rackpack. Schwarz. Tailbag Rackpack. Black. 02 – 04 [BC.HTA.00.305.10000](#)
 Hecktasche Cargobag. Schwarz. Tailbag Cargobag. Black. 02 – 04 [BC.HTA.00.306.10000](#)
 Hecktasche Racepack®. Schwarz. Tailbag Racepack®. Black. 02 – 04 [BC.HTA.00.302.10000](#)
 Hecktasche Speedpack®. Schwarz. Tailbag Speedpack®. Black. 02 – 04 [BC.HTA.00.301.10000](#)
 Hecktasche Drybag M. Anthrazit/Schwarz. Tailbag Drybag M. Anthracite/Black. 02 – 04 [BC.WPB.00.001.10000](#)
 Hecktasche Drybag M. Neon-Gelb. Tailbag Drybag M. Neon-Yellow. 02 – 04 [BCK.HTA.00.053.100/Y](#)



Speed Triple 955



- 1 Hecktasche Slipstream. Schwarz. Tailbag Slipstream. Black. 97 – 05 [BC.HTA.00.307.10000](#)
- 2 Hecktasche Rearbag. Schwarz. Tailbag Rearbag. Black. 97 – 05 [BC.HTA.00.304.10000](#)
 Hecktasche Rackpack. Schwarz. Tailbag Rackpack. Black. 00 – 04 [BC.HTA.00.305.10000](#)
 Hecktasche Cargobag. Schwarz. Tailbag Cargobag. Black. 00 – 04 [BC.HTA.00.306.10000](#)
- 3 Hecktasche Racepack®. Schwarz. Tailbag Racepack®. Black. 00 – 04 [BC.HTA.00.302.10000](#)
 Hecktasche Speedpack®. Schwarz. Tailbag Speedpack®. Black. 00 – 04 [BC.HTA.00.301.10000](#)
 Hecktasche Drybag M. Anthrazit/Schwarz. Tailbag Drybag M. Anthracite/Black. 00 – 04 [BC.WPB.00.001.10000](#)
 Hecktasche Drybag M. Neon-Gelb. Tailbag Drybag M. Neon-Yellow. 00 – 04 [BCK.HTA.00.053.100/Y](#)
 Lenkererhöhung. Schwarz. ø 22 mm. h 30 mm. Bar Riser. Black. ø 22 mm. h 30 mm. 00 – 05 [LEH.00.039.150/30/B](#)
 Lenkererhöhung. Silber. ø 22 mm. h 30 mm. Bar Riser. Silver. ø 22 mm. h 30 mm. 00 – 05 [LEH.00.039.150/30/S](#)
 Lenkerverlegung. Schwarz. Barback. Black. 00 – 05 [LEH.00.039.152/B](#)
 Lenkerverlegung. Silber. Barback. Silver. 00 – 05 [LEH.00.039.152/S](#)
- 4 Lenker-Konverter-Set. Schwarz. Bar Converter Set. Black. 00 – 04 [LEH.00.039.168/B](#)
 Lenker-Konverter-Set. Schwarz. Bar Converter Set. Black. 01 – 05 [LEH.00.039.168/B](#)
 Lenker-Konverter-Set. Silber. Bar Converter Set. Silver. 00 – 04 [LEH.00.039.168/S](#)
 Lenker-Konverter-Set. Silber. Bar Converter Set. Silver. 01 – 05 [LEH.00.039.168/S](#)
- 4 Hauptständer. Schwarz. Centerstand. Black. 97 – 02 [HPS.11.292.10000/B](#)





- QUICK-LOCK EVO Tankring. Schwarz. QUICK-LOCK EVO Tankring. Black. 04 – 06 [TRT.00.640.16000/B](#)
 QUICK-LOCK EVO Micro. Schwarz. QUICK-LOCK EVO Micro. Black. 04 – 06 [BC.TRS.00.110.20000](#)
 QUICK-LOCK EVO Daypack. Schwarz. QUICK-LOCK EVO Daypack. Black. 04 – 06 [BC.TRS.00.108.20000](#)
1 QUICK-LOCK EVO Engage. Schwarz. QUICK-LOCK EVO Engage. Black. 04 – 06 [BC.TRS.00.107.20000](#)
 QUICK-LOCK EVO Trial. Schwarz. QUICK-LOCK EVO Trial. Black. 04 – 06 [BC.TRS.00.102.20000](#)
 QUICK-LOCK EVO Elektrik Micro. Schwarz. QUICK-LOCK EVO Electric Micro. Black. 04 – 06 [BC.TRE.00.110.20000](#)
 QUICK-LOCK EVO Elektrik Daypack. Schwarz. QUICK-LOCK EVO Electric Daypack. Black. 04 – 06 [BC.TRE.00.108.20000](#)
 QUICK-LOCK EVO Elektrik Engage. Schwarz. QUICK-LOCK EVO Electric Engage. Black. 04 – 06 [BC.TRE.00.107.20000](#)
 QUICK-LOCK EVO Elektrik Trial. Schwarz. QUICK-LOCK EVO Electric Trial. Black. 04 – 06 [BC.TRE.00.102.20000](#)
2 ALU-RACK. Schwarz. ALU-RACK. Black. 00 – 06 [GPT.11.530.100/B](#)
 QUICK-LOCK Kofferträger. Schwarz. QUICK-LOCK Side Carrier. Black. 00 – 06 [KFT.11.255.100](#)
3 Hecktasche Slipstream. Schwarz. Tailbag Slipstream. Black. 00 – 06 [BC.HTA.00.307.10000](#)
 Hecktasche Rearbag. Schwarz. Tailbag Rearbag. Black. 00 – 06 [BC.HTA.00.304.10000](#)
 Hecktasche Rackpack. Schwarz. Tailbag Rackpack. Black. 00 – 06 [BC.HTA.00.305.10000](#)
4 Hecktasche Cargobag. Schwarz. Tailbag Cargobag. Black. 00 – 06 [BC.HTA.00.306.10000](#)
 Hecktasche Speedpack®. Schwarz. Tailbag Speedpack®. Black. 00 – 06 [BC.HTA.00.301.10000](#)
 Hecktasche Drybag M. Anthrazit/Schwarz. Tailbag Drybag M. Anthracite/Black. 00 – 06 [BC.WPB.00.001.10000](#)
 Hecktasche Drybag L. Anthrazit/Schwarz. Tailbag Drybag L. Anthracite/Black. 00 – 06 [BC.WPB.00.002.10000](#)
 Hecktasche Drybag L. Neon-Gelb. Tailbag Drybag L. Neon-Yellow. 00 – 06 [BCK.HTA.00.047.100/Y](#)
 Spiegelverlängerung. Schwarz. Lenkerausleger. Mirror Extension. Black. Universal. 00 – 06 [SVL.00.505.101](#)
 Lenkererhöhung. Schwarz. Bar Riser. Black. 00 – 07 [LEH.00.039.150/30/B](#)
 Lenkererhöhung. Silber. Bar Riser. Silver. 00 – 07 [LEH.00.039.150/30/S](#)
 Lenkerverlegung. Schwarz. Barback. Black. 00 – 07 [LEH.00.039.152/B](#)
 Lenkerverlegung. Silber. Barback. Silver. 00 – 07 [LEH.00.039.152/S](#)
 Lenker-Konverter-Set. Schwarz. Bar Converter Set. Black. 00 – 07 [LEH.00.039.168/B](#)
 Lenker-Konverter-Set. Silber. Bar Converter Set. Silver. 00 – 07 [LEH.00.039.168/S](#)
 Hauptständer. Schwarz. Centerstand. Black. 00 – 06 [HPS.11.531.100](#)



- QUICK-LOCK EVO Tankring. Schwarz. QUICK-LOCK EVO Tankring. Black. 04 – [TRT.00.640.16000/B](#)
 QUICK-LOCK EVO Micro. Schwarz. QUICK-LOCK EVO Micro. Black. 04 – [BC.TRS.00.110.20000](#)
 QUICK-LOCK EVO Daypack. Schwarz. QUICK-LOCK EVO Daypack. Black. 04 – [BC.TRS.00.108.20000](#)
 QUICK-LOCK EVO Sport. Schwarz. QUICK-LOCK EVO Sport. Black. 04 – [BC.TRS.00.101.20000](#)
 QUICK-LOCK EVO Elektrik Micro. Schwarz. QUICK-LOCK EVO Electric Micro. Black. 04 – [BC.TRE.00.110.20000](#)
 QUICK-LOCK EVO Elektrik Daypack. Schwarz. QUICK-LOCK EVO Electric Daypack. Black. 04 – [BC.TRE.00.108.20000](#)
 QUICK-LOCK EVO Elektrik Sport. Schwarz. QUICK-LOCK EVO Electric Sport. Black. 04 – [BC.TRE.00.101.20000](#)
 BLAZE® Satteltaschen-Set. Schwarz. BLAZE® Panniers Set. Black. 08 – 10 [BC.HTA.11.740.10300/B](#)
1 BLAZE® H Satteltaschen-Set. Schwarz. BLAZE® H Panniers Set. Black. 10 – 12 [BC.HTA.11.740.10100/B](#)
 ALU-RACK. Schwarz. ALU-RACK. Black. 04 – 07 [GPT.11.259.15000/B](#)
 ALU-RACK. Schwarz. ALU-RACK. Black. 08 – 10 [GPT.11.502.15000/B](#)
2 ALU-RACK. Schwarz. ALU-RACK. Black. 10 – [GPT.11.183.15000/B](#)
 Hecktasche Slipstream. Schwarz. Tailbag Slipstream. Black. 04 – [BC.HTA.00.307.10000](#)
 Hecktasche Rearbag. Schwarz. Tailbag Rearbag. Black. 04 – [BC.HTA.00.304.10000](#)
 Hecktasche Rackpack. Schwarz. Tailbag Rackpack. Black. 04 – [BC.HTA.00.305.10000](#)
 Hecktasche Racepack®. Schwarz. Tailbag Racepack®. Black. 04 – [BC.HTA.00.302.10000](#)
 Nonshock Endurance Lenker S. Schwarz. Nonshock Endurance Bar S. Black. 06 – 10 [LEN.00.156.11000/B](#)
 Lenkeraufnahme. Schwarz. ø 28 mm. M10. ABE nur in Verbindung mit Sonderlenker. Bar Mount. Black. ø 28 mm. M10.
 TÜV-certified when used with special handlebar. 06 – 10 [LEH.00.039.16200.04/B](#)
 Lenkeraufnahme. Silber. ø 28 mm. M10. ABE nur in Verbindung mit Sonderlenker. Bar Mount. Silver. ø 28 mm. M10.
 TÜV-certified when used with special handlebar. 06 – 10 [LEH.00.039.16200.04/S](#)
 Lenkererhöhung. Schwarz. ø 28 mm. h 30 mm. Bar Riser. Black. ø 28 mm. h 30 mm. 10 – [LEH.00.039.20300/B](#)
 Lenkererhöhung. Silber. ø 28 mm. h 30 mm. Bar Riser. Silver. ø 28 mm. h 30 mm. 10 – [LEH.00.039.20300/S](#)
3 Nonshock GPS-Halter Cockpit. Schwarz. Nonshock Cockpit GPS Mount. Black. 04 – 07 [GPS.11.643.10000/B](#)
 Nonshock GPS-Halter Cockpit. Schwarz. Nonshock Cockpit GPS Mount. Black. 08 – 10 [GPS.11.692.10000/B](#)
 QUICK-LOCK GPS-Halter. Schwarz. QUICK-LOCK GPS Mount. Black. 04 – 07 [GPS.00.646.10000/B](#)
 QUICK-LOCK GPS-Halter. Schwarz. QUICK-LOCK GPS Mount. Black. 08 – 10 [GPS.11.646.10000/B](#)
 QUICK-LOCK GPS-Halter. Schwarz. QUICK-LOCK GPS Mount. Black. 10 – [GPS.11.646.10300/B](#)
 Spiegelverlängerung. Schwarz. Lenkerausleger. Mirror Extension. Black. Universal. 04 – [SVL.00.505.101](#)
 Sturzpad-Kit. Frame Slider Kit. 04 – 10 [STP.11.590.10000/B](#)
4 Sturzpad-Kit. Frame Slider Kit. 10 – [STP.11.590.10300/B](#)
 Fußrasten-Kit. Silber. Footrest Kit. Silver. 04 – 07 [FRS.01.011.10400/S](#)
 Hauptständer. Schwarz. Centerstand. Black. 04 – 10 [HPS.11.292.10000/B](#)
 Hauptständer. Schwarz. Centerstand. Black. 10 – [HPS.11.130.10000/B](#)





Speed Triple 1050 R

- QUICK-LOCK EVO Tankring, Schwarz. QUICK-LOCK EVO Tankring, Black. 10 – [TRT.00.640.16000/B](#)
- 1 QUICK-LOCK EVO Micro, Schwarz. QUICK-LOCK EVO Micro, Black. 10 – [BC.TRS.00.110.20000](#)
- QUICK-LOCK EVO Daypack, Schwarz. QUICK-LOCK EVO Daypack, Black. 10 – [BC.TRS.00.108.20000](#)
- QUICK-LOCK EVO Sport, Schwarz. QUICK-LOCK EVO Sport, Black. 10 – [BC.TRS.00.101.20000](#)
- QUICK-LOCK EVO Elektrik Micro, Schwarz. QUICK-LOCK EVO Electric Micro, Black. 10 – [BC.TRE.00.110.20000](#)
- QUICK-LOCK EVO Elektrik Daypack, Schwarz. QUICK-LOCK EVO Electric Daypack, Black. 10 – [BC.TRE.00.108.20000](#)
- QUICK-LOCK EVO Elektrik Sport, Schwarz. QUICK-LOCK EVO Electric Sport, Black. 10 – [BC.TRE.00.101.20000](#)
- BLAZE® H Satteltaschen-Set, Schwarz. BLAZE® H Panniers Set, Black. 10 – [BC.HTA.11.740.10100/B](#)
- ALU-RACK, Schwarz. ALU-RACK, Black. 10 – [GPT.11.183.15000/B](#)
- Hecktasche Slipstream, Schwarz. Tailbag Slipstream, Black. 10 – [BC.HTA.00.307.10000](#)
- 2 Hecktasche Rearbag, Schwarz. Tailbag Rearbag, Black. 10 – [BC.HTA.00.304.10000](#)
- Hecktasche Rackpack, Schwarz. Tailbag Rackpack, Black. 10 – [BC.HTA.00.305.10000](#)
- Spiegelverlängerung, Schwarz. Lenker ausleger. Mirror Extension, Black, Universal. 10 – [SVL.00.505.101](#)
- Lenkererhöhung, Schwarz, ø 28 mm, h 30 mm. Bar Riser, Black, ø 28 mm, h 30 mm. 10 – [LEH.00.039.20300/B](#)
- Lenkererhöhung, Silber, ø 28 mm, h 30 mm. Bar Riser, Silver, ø 28 mm, h 30 mm. 10 – [LEH.00.039.20300/S](#)
- QUICK-LOCK GPS-Halter, Schwarz. QUICK-LOCK GPS Mount, Black. 10 – [GPS.11.646.10300/B](#)
- Sturzpad-Kit Frame Slider Kit 10 – [STP.11.590.10300/B](#)



Sprint GT

- 3 QUICK-LOCK EVO Tankring, Schwarz. QUICK-LOCK EVO Tankring, Black. 10 – [TRT.00.640.16000/B](#)
- QUICK-LOCK EVO Micro, Schwarz. QUICK-LOCK EVO Micro, Black. 10 – [BC.TRS.00.110.20000](#)
- QUICK-LOCK EVO Daypack, Schwarz. QUICK-LOCK EVO Daypack, Black. 10 – [BC.TRS.00.108.20000](#)
- QUICK-LOCK EVO City, Schwarz. QUICK-LOCK EVO City, Black. 10 – [BC.TRS.00.104.20000](#)
- QUICK-LOCK EVO Sport, Schwarz. QUICK-LOCK EVO Sport, Black. 10 – [BC.TRS.00.101.20000](#)
- QUICK-LOCK EVO Trial, Schwarz. QUICK-LOCK EVO Trial, Black. 10 – [BC.TRS.00.102.20000](#)
- QUICK-LOCK EVO Elektrik Micro, Schwarz. QUICK-LOCK EVO Electric Micro, Black. 10 – [BC.TRE.00.110.20000](#)
- QUICK-LOCK EVO Elektrik Daypack, Schwarz. QUICK-LOCK EVO Electric Daypack, Black. 10 – [BC.TRE.00.108.20000](#)
- QUICK-LOCK EVO Elektrik City, Schwarz. QUICK-LOCK EVO Electric City, Black. 10 – [BC.TRE.00.104.20000](#)
- QUICK-LOCK EVO Elektrik Sport, Schwarz. QUICK-LOCK EVO Electric Sport, Black. 10 – [BC.TRE.00.101.20000](#)
- QUICK-LOCK EVO Elektrik Trial, Schwarz. QUICK-LOCK EVO Electric Trial, Black. 10 – [BC.TRE.00.102.20000](#)



- BLAZE® Satteltaschen-Set, Schwarz. BLAZE® Panniers Set, Black. 10 – [BC.HTA.11.740.10000/B](#)
- ALU-RACK, Schwarz. ALU-RACK, Black. 10 – [GPT.11.744.10000/B](#)
- Hecktasche Slipstream, Schwarz. Tailbag Slipstream, Black. 10 – [BC.HTA.00.307.10000](#)
- Hecktasche Rackpack, Schwarz. Tailbag Rackpack, Black. 10 – [BC.HTA.00.305.10000](#)
- Hecktasche Speedpack®, Schwarz. Tailbag Speedpack®, Black. 10 – [BC.HTA.00.301.10000](#)
- Hecktasche Drybag M. Anthrazit/Schwarz. Tailbag Drybag M. Anthracite/Black. 10 – [BC.WPB.00.001.10000](#)
- Hecktasche Drybag M. Neon-Gelb. Tailbag Drybag M. Neon-Yellow. 10 – [BCK.HTA.00.053.100/Y](#)
- 4 Spiegelverlängerung, Schwarz. Kontur-Distanzstück. Mirror Extension, Black, Profile. 10 – [SVL.11.501.10100/B](#)
- QUICK-LOCK GPS-Halter, Schwarz. QUICK-LOCK GPS Mount, Black. 10 – [GPS.11.646.10100/B](#)
- 5 Sturzpad-Kit Frame Slider Kit 10 – [STP.11.590.10200/B](#)

Sprint ST 1050

- QUICK-LOCK EVO Tankring, Schwarz. QUICK-LOCK EVO Tankring, Black. 05 – [TRT.00.640.16000/B](#)
- 6 QUICK-LOCK Kofferträger, Schwarz. QUICK-LOCK Side Carrier, Black. 05 – [KFT.11.528.100](#)
- 7 ALU-RACK, Schwarz. ALU-RACK, Black. 05 – [GPT.11.527.15000/B](#)
- Hecktasche Slipstream, Schwarz. Tailbag Slipstream, Black. 05 – [BC.HTA.00.307.10000](#)
- Hecktasche Rearbag, Schwarz. Tailbag Rearbag, Black. 05 – [BC.HTA.00.304.10000](#)
- Hecktasche Rackpack, Schwarz. Tailbag Rackpack, Black. 05 – [BC.HTA.00.305.10000](#)
- Hecktasche Cargobag, Schwarz. Tailbag Cargobag, Black. 05 – [BC.HTA.00.306.10000](#)
- Hecktasche Speedpack®, Schwarz. Tailbag Speedpack®, Black. 05 – [BC.HTA.00.301.10000](#)
- Hecktasche Drybag M. Anthrazit/Schwarz. Tailbag Drybag M. Anthracite/Black. 05 – [BC.WPB.00.001.10000](#)
- Hecktasche Drybag M. Neon-Gelb. Tailbag Drybag M. Neon-Yellow. 05 – [BCK.HTA.00.053.100/Y](#)
- QUICK-LOCK GPS-Halter, Schwarz. QUICK-LOCK GPS Mount, Black. 05 – [GPS.11.646.10100/B](#)



TRIUMPH

Tiger 1050



- QUICK-LOCK EVO Tankring. Schwarz. QUICK-LOCK EVO Tankring. Black. 06 - 11 ☎ [TRT.00.640.16000/B](#)
 QUICK-LOCK EVO Micro. Schwarz. QUICK-LOCK EVO Micro. Black. 06 - 11 ☎ [BC.TRS.00.110.20000](#)
 QUICK-LOCK EVO Daypack. Schwarz. QUICK-LOCK EVO Daypack. Black. 06 - 11 ☎ [BC.TRS.00.108.20000](#)
- 1** QUICK-LOCK EVO City. Schwarz. QUICK-LOCK EVO City. Black. 06 - 11 ☎ [BC.TRS.00.104.20000](#)
 QUICK-LOCK EVO Elektrik Micro. Schwarz. QUICK-LOCK EVO Electric Micro. Black. 06 - 11 ☎ [BC.TRE.00.110.20000](#)
 QUICK-LOCK EVO Elektrik Daypack. Schwarz. QUICK-LOCK EVO Electric Daypack. Black. 06 - 11 ☎ [BC.TRE.00.108.20000](#)
 QUICK-LOCK EVO Elektrik City. Schwarz. QUICK-LOCK EVO Electric City. Black. 06 - 11 ☎ [BC.TRE.00.104.20000](#)
- 2** QUICK-LOCK EVO Kofferträger. Schwarz. QUICK-LOCK EVO Side Carrier. Black. 06 - 11 ☎ [KFT.11.605.200](#)
 TraX® EVO Koffersystem. Schwarz. 45/37 l. TraX® EVO Pannier System. Black. 45/37 l. 06 - 11 ☎ [KFT.11.605.50000/B](#)
- 3** TraX® EVO Koffersystem. Silber. 45/37 l. TraX® EVO Pannier System. Silver. 45/37 l. 06 - 11 ☎ [KFT.11.605.50000/S](#)
- 4** ALU-RACK. Silber. ALU-RACK. Silver. 06 - 11 ☎ [GPT.11.619.100/S](#)
 ALU-RACK. Schwarz. ALU-RACK. Black. 06 - 11 ☎ [GPT.11.619.15000/B](#)
 Hecktasche Slipstream. Schwarz. Tailbag Slipstream. Black. 06 - 11 ☎ [BC.HTA.00.307.10000](#)
 Hecktasche Jetpack. Schwarz. Tailbag Jetpack. Black. 06 - 11 ☎ [BC.HTA.00.303.10000](#)
 Hecktasche Rearbag. Schwarz. Tailbag Rearbag. Black. 06 - 11 ☎ [BC.HTA.00.304.10000](#)
 Hecktasche Rackpack. Schwarz. Tailbag Rackpack. Black. 06 - 11 ☎ [BC.HTA.00.305.10000](#)
 Hecktasche Cargobag. Schwarz. Tailbag Cargobag. Black. 06 - 11 ☎ [BC.HTA.00.306.10000](#)
 Hecktasche Speedpack®. Schwarz. Tailbag Speedpack®. Black. 06 - 11 ☎ [BC.HTA.00.301.10000](#)



- Hecktasche Drybag M. Anthrazit/Schwarz. Tailbag Drybag M. Anthracite/Black. 06 - 11 ☎ [BC.WPB.00.001.10000](#)
 Hecktasche Drybag L. Anthrazit/Schwarz. Tailbag Drybag L. Anthracite/Black. 06 - 11 ☎ [BC.WPB.00.002.10000](#)
 Hecktasche Drybag L. Neon-Gelb. Tailbag Drybag L. Neon-Yellow. 06 - 11 ☎ [BCK.HTA.00.047.100/Y](#)
 Lenkererhöhung. Schwarz. ø 22 mm. h 30 mm. Bar Riser. Black. ø 22 mm. h 30 mm. 06 - 11 + [LEH.00.039.150/30/B](#)
 Lenkererhöhung. Silber. ø 22 mm. h 30 mm. Bar Riser. Silver. ø 22 mm. h 30 mm. 06 - 11 + [LEH.00.039.150/30/S](#)
 Lenkeraufnahme. Schwarz. ø 28 mm. M10. ABE nur in Verbindung mit Sonderlenker. Bar Mount. Black. ø 28 mm. M10. TÜV-specified when used with special handlebar. 06 - 11 + [LEH.00.039.16200.07/B](#)
 Lenkeraufnahme. Silber. ø 28 mm. M10. ABE nur in Verbindung mit Sonderlenker. Bar Mount. Silver. ø 28 mm. M10. TÜV-specified when used with special handlebar. 06 - 11 + [LEH.00.039.16200.07/S](#)
 Nonschok Endurance Lenker. Schwarz. Nonschok Endurance Bar. Black. 06 - 11 + [LEN.00.156.10001/B](#)
 Spiegelverlängerung. Schwarz. Lenker ausleger. Mirror Extension. Black. Universal. 06 - 11 + [SVL.00.505.101](#)
 BB STORM Handprotektoren-Kit. Schwarz. BB STORM Handguard Kit. Black. 06 - 11 ☎ [HPR.00.220.10900/B](#)
 KOBRA Handprotektoren-Kit. Schwarz. KOBRA Handguard Kit. Black. 06 - 11 ☎ [HPR.00.220.20900/B](#)
 QUICK-LOCK GPS-Halter. Schwarz. QUICK-LOCK GPS Mount. Black. 06 - 11 ☎ [GPS.00.646.10000/B](#)
 HAWK Scheinwerferklemmen-Set. Schwarz. HAWK Light Clamp Set. Black. 06 - 11 ☎ [NSW.00.004.13000/B](#)
 HAWK Scheinwerferhalter-Set. Schwarz. HAWK Light Mount Set. Black. 06 - 11 ☎ [NSW.11.004.10000/B](#)
5 HAWK Nebelscheinwerfer-Set. Schwarz. HAWK Fog Light Set. Black. 06 - 11 ☎ [NSW.11.004.50000/B](#)
 HAWK Nebelscheinwerfer-Set. Silber. HAWK Fog Light Set. Silver. 06 - 11 ☎ [NSW.11.004.50000/S](#)
6 Schutzbügel. Schwarz. Crashbar. Black. 06 - 11 ☎ [SBL.11.610.100](#)
 Vorderachs-Sturzpadd-Kit. Schwarz. Front Axle Slider Kit. Black. 06 - 11 ☎ [STP.11.176.10300/B](#)
 Hinterachs-Sturzpadd-Kit. Schwarz. Rear Axle Slider Kit. Black. 06 - 11 ☎ [STP.11.176.10400/B](#)
7 Kettenschutz. Silber. Chain Guard. Silver. 06 - 11 ☎ [KTS.11.515.100](#)
 Kettenschutz. Schwarz. Chain Guard. Black. 06 - 11 ☎ [KTS.11.515.10000/B](#)
8 Motorschutz. Silber. Engine Guard. Silver. 06 - 11 ☎ [MSS.11.520.100](#)
 Motorschutz. Schwarz. Engine Guard. Black. 06 - 11 ☎ [MSS.11.520.10000/B](#)
 Fußrasten-Kit. Silber. Footrest Kit. Silver. 06 - 11 + [FRS.11.011.10000/S](#)
 Hauptständer. Schwarz. Centerstand. Black. 06 - 11 + [HPS.11.611.100](#)



TRIUMPH

Tiger 1050 SE



- QUICK-LOCK EVO Tankring. Schwarz. QUICK-LOCK EVO Tankring. Black. 11 – [TRT.00.640.16000/B](#)
- 1** QUICK-LOCK EVO Micro. Schwarz. QUICK-LOCK EVO Micro. Black. 11 – [BC.TRS.00.110.20000](#)
- QUICK-LOCK EVO Daypack. Schwarz. QUICK-LOCK EVO Daypack. Black. 11 – [BC.TRS.00.108.20000](#)
- QUICK-LOCK EVO City. Schwarz. QUICK-LOCK EVO City. Black. 11 – [BC.TRS.00.104.20000](#)
- 2** QUICK-LOCK EVO GS. Schwarz. QUICK-LOCK EVO GS. Black. 11 – [BC.TRS.00.103.20000](#)
- QUICK-LOCK EVO Elektrik Micro. Schwarz. QUICK-LOCK EVO Electric Micro. Black. 11 – [BC.TRE.00.110.20000](#)
- QUICK-LOCK EVO Elektrik Daypack. Schwarz. QUICK-LOCK EVO Electric Daypack. Black. 11 – [BC.TRE.00.108.20000](#)
- QUICK-LOCK EVO Elektrik City. Schwarz. QUICK-LOCK EVO Electric City. Black. 11 – [BC.TRE.00.104.20000](#)
- QUICK-LOCK EVO Elektrik GS. Schwarz. QUICK-LOCK EVO Electric GS. Black. 11 – [BC.TRE.00.103.20000](#)
- 3** ALU-RACK. Schwarz. ALU-RACK. Black. 11 – [GPT.11.527.15000/B](#)
- Hecktasche Slipstream. Schwarz. Tailbag Slipstream. Black. 11 – [BC.HTA.00.307.10000](#)
- Hecktasche Jetpack. Schwarz. Tailbag Jetpack. Black. 11 – [BC.HTA.00.303.10000](#)
- Hecktasche Rearbag. Schwarz. Tailbag Rearbag. Black. 11 – [BC.HTA.00.304.10000](#)
- Hecktasche Rackpack. Schwarz. Tailbag Rackpack. Black. 11 – [BC.HTA.00.305.10000](#)
- 4** Hecktasche Cargobag. Schwarz. Tailbag Cargobag. Black. 11 – [BC.HTA.00.306.10000](#)
- Hecktasche Drybag M. Anthrazit/Schwarz. Tailbag Drybag M. Anthracite/Black. 11 – [BC.WPB.00.001.10000](#)
- 5** Hecktasche Drybag L. Anthrazit/Schwarz. Tailbag Drybag L. Anthracite/Black. 11 – [BC.WPB.00.002.10000](#)



TRIUMPH

Tiger 1050 SE



- Hecktasche Drybag L. Neon-Gelb. Tailbag Drybag L. Neon-Yellow. 11 – [BCK.HTA.00.047.100/Y](#)
- Nonshock Endurance Lenker S. Schwarz. Nonshock Endurance Bar S. Black. 11 – [LEN.00.156.11000/B](#)
- 6** Lenkererhöhung. Silber. h 30 mm. Handlebar Riser. Silver. h 30 mm. 11 – [LEH.11.039.10100/S](#)
- BB STORM Handprotektoren-Kit. Schwarz. BB STORM Handguard Kit. Black. 11 – [HPR.00.220.10900/B](#)
- KOBRA Handprotektoren-Kit. Schwarz. KOBRA Handguard Kit. Black. 11 – [HPR.00.220.20900/B](#)
- Spiegelverlängerung. Schwarz. Lenkerausleger. Mirror Extension. Black. Universal. 11 – [SVL.00.505.101](#)
- QUICK-LOCK GPS-Halter. Schwarz. QUICK-LOCK GPS Mount. Black. 11 – [GPS.11.646.10201/B](#)
- HAWK Scheinwerferklemmen-Set. Schwarz. HAWK Light Clamp Set. Black. 11 – [NSW.00.004.13000/B](#)
- HAWK Scheinwerferhalter-Set. Schwarz. HAWK Light Mount Set. Black. 11 – [NSW.11.004.10000/B](#)
- HAWK Nebelscheinwerfer-Set. Schwarz. HAWK Fog Light Set. Black. 11 – [NSW.11.004.50000/B](#)
- HAWK Nebelscheinwerfer-Set. Silber. HAWK Fog Light Set. Silver. 11 – [NSW.11.004.50000/S](#)
- 7** Schutzbügel. Schwarz. Crashbar. Black. 11 – [SBL.11.610.100](#)
- Vorderachs-Sturzpad-Kit. Schwarz. Front Axle Slider Kit. Black. 11 – [STP.11.176.10300/B](#)
- Hinterachs-Sturzpad-Kit. Schwarz. Rear Axle Slider Kit. Black. 11 – [STP.11.176.10400/B](#)
- Kettenschutz. Schwarz. Chain Guard. Black. 11 – [KTS.11.515.10000/B](#)
- 8** Fußrasten-Kit. Silber. Footrest Kit. Silver. 11 – [FRS.11.011.10000/S](#)
- 9** Motorschutz. Schwarz. Engine Guard. Black. 11 – [MSS.11.520.10000/B](#)



TRIUMPH

Tiger Explorer



- QUICK-LOCK EVO Tankring. Schwarz. QUICK-LOCK EVO Tankring. Black. 11 – [TRT.00.640.16000/B](#)
- QUICK-LOCK EVO Micro. Schwarz. QUICK-LOCK EVO Micro. Black. 11 – [BC.TRS.00.110.20000](#)
- QUICK-LOCK EVO City. Schwarz. QUICK-LOCK EVO City. Black. 11 – [BC.TRS.00.104.20000](#)
- 1** QUICK-LOCK EVO GS. Schwarz. QUICK-LOCK EVO GS. Black. 11 – [BC.TRS.00.103.20000](#)
- QUICK-LOCK EVO Elektrik Micro. Schwarz. QUICK-LOCK EVO Electric Micro. Black. 11 – [BC.TRE.00.110.20000](#)
- QUICK-LOCK EVO Elektrik City. Schwarz. QUICK-LOCK EVO Electric City. Black. 11 – [BC.TRE.00.104.20000](#)
- QUICK-LOCK EVO Elektrik GS. Schwarz. QUICK-LOCK EVO Electric GS. Black. 11 – [BC.TRE.00.103.20000](#)
- 2** QUICK-LOCK EVO Kofferträger. Schwarz. QUICK-LOCK EVO Side Carrier. Black. 11 – [KFT.11.483.20000/B](#)
- TraX® EVO Koffersystem. Schwarz. 37/37 l. TraX® EVO Pannier System. Black. 37/37 l. 11 – [KFT.11.483.50000/B](#)
- TraX® EVO Koffersystem. Silber. 37/37 l. TraX® EVO Pannier System. Silver. 37/37 l. 11 – [KFT.11.483.50000/S](#)
- TraX® EVO Koffersystem. Schwarz. 45/45 l. TraX® EVO Pannier System. Black. 45/45 l. 11 – [KFT.11.483.50100/B](#)
- TraX® EVO Koffersystem. Silber. 45/45 l. TraX® EVO Pannier System. Silver. 45/45 l. 11 – [KFT.11.483.50100/S](#)
- 3** AERO ABS-Seitenkoffersystem. Schwarz. AERO ABS Sidecase System. Black. 11 – [KFT.11.483.60000/B](#)
- 4** ALU-RACK. Schwarz. ALU-RACK. Black. 11 – [GPT.11.482.15000/B](#)
- STEEL-RACK. Schwarz. STEEL-RACK. Black. 11 – [GPT.11.482.20001/B](#)
- Hecktasche Slipstream. Schwarz. Tailbag Slipstream. Black. 11 – [BC.HTA.00.307.10000](#)
- Hecktasche Jetpack. Schwarz. Tailbag Jetpack. Black. 11 – [BC.HTA.00.303.10000](#)
- Hecktasche Rearbag. Schwarz. Tailbag Rearbag. Black. 11 – [BC.HTA.00.304.10000](#)
- Hecktasche Rackpack. Schwarz. Tailbag Rackpack. Black. 11 – [BC.HTA.00.305.10000](#)
- Hecktasche Cargobag. Schwarz. Tailbag Cargobag. Black. 11 – [BC.HTA.00.306.10000](#)
- Hecktasche Speedpack®. Schwarz. Tailbag Speedpack®. Black. 11 – [BC.HTA.00.301.10000](#)



- Hecktasche Drybag M. Anthrazit/Schwarz. Tailbag Drybag M. Anthracite/Black. 11 – [BC.WPB.00.001.10000](#)
- Hecktasche Drybag L. Anthrazit/Schwarz. Tailbag Drybag L. Anthracite/Black. 11 – [BC.WPB.00.002.10000](#)
- Hecktasche Drybag L. Neon-Gelb. Tailbag Drybag L. Neon-Yellow. 11 – [BCK.HTA.00.047.100/Y](#)
- 5** Scheinwerferschutz. Schwarz. Headlight Protection. Black. 11 – [LPS.11.124.10000/B](#)
- HAWK Scheinwerferhalter-Set. Schwarz. HAWK Light Mount Set. Black. 11 – [NSW.11.004.10200/B](#)
- HAWK Nebelscheinwerfer-Set. Schwarz. HAWK Fog Light Set. Black. 11 – [NSW.11.004.50200/B](#)
- 6** HAWK Nebelscheinwerfer-Set. Silber. HAWK Fog Light Set. Silver. 11 – [NSW.11.004.50200/S](#)
- Lenkererhöhung. Silber. h 20 mm. Bar Riser. Silver. h 20 mm. 11 – [LEH.11.039.10000/S](#)
- BB STORM Handprotektoren-Kit. Schwarz. BB STORM Handguard Kit. Black. 11 – [HPR.00.220.10500/B](#)
- KOBRA Handprotektoren-Kit. Schwarz. KOBRA Handguard Kit. Black. 11 – [HPR.00.220.20500/B](#)
- Spiegelverlängerung. Schwarz. Lenker ausleger. Mirror Extension. Black. Universal. 11 – [SVL.00.505.10500/B](#)
- QUICK-LOCK GPS-Halter. Schwarz. QUICK-LOCK GPS Mount. Black. 11 – [GPS.11.646.10201/B](#)
- Schutzbügel. Schwarz. Crashbar. Black. 11 – [SBL.11.485.10000/B](#)
- Schalthebel Gear Lever 11 – [FSC.11.127.10100/B](#)
- Vorderachs-Sturzpadd-Kit. Schwarz. Front Axle Slider Kit. Black. 11 – [STP.11.176.10200/B](#)
- Fußrasten-Kit. Silber. Footrest Kit. Silver. 11 – [FRS.11.011.10101/S](#)
- Seitenständerfuß. Silber. Sidestand Foot. Silver. 11 – [STS.11.102.10100/S](#)
- 7** Motorschutz. Silber. Engine Guard. Silver. 11 – [MSS.11.484.10000/S](#)
- 8** Motorschutz Verlängerung. Silber. Engine Guard Extension. Silver. 11 – [MSS.11.486.10000/S](#)



Tiger Explorer XC

- Hecktasche Slipstream. Schwarz. Tailbag Slipstream. Black. 12 – [BC.HTA.00.307.10000](#)
- Hecktasche Jetpack. Schwarz. Tailbag Jetpack. Black. 12 – [BC.HTA.00.303.10000](#)
- Hecktasche Rearbag. Schwarz. Tailbag Rearbag. Black. 12 – [BC.HTA.00.304.10000](#)
- Hecktasche Rackpack. Schwarz. Tailbag Rackpack. Black. 12 – [BC.HTA.00.305.10000](#)
- Hecktasche Cargobag. Schwarz. Tailbag Cargobag. Black. 12 – [BC.HTA.00.306.10000](#)
- Hecktasche Racepack®. Schwarz. Tailbag Racepack®. Black. 12 – [BC.HTA.00.302.10000](#)
- Hecktasche Drybag M. Anthrazit/Schwarz. Tailbag Drybag M. Anthracite/Black. 12 – [BC.WPB.00.001.10000](#)
- Hecktasche Drybag L. Anthrazit/Schwarz. Tailbag Drybag L. Anthracite/Black. 12 – [BC.WPB.00.002.10000](#)
- Hecktasche Drybag L. Neon-Gelb. Tailbag Drybag L. Neon-Yellow. 12 – [BCK.HTA.00.047.100/Y](#)





SW-MOTECH GmbH & Co. KG

BAGS-CONNECTION GmbH & Co. KG

Ernteweg 8/10 . 35282 Rauschenberg . Germany

phone +49 6425 8168-050 . fax +49 6425 8168-10

info@sw-bc.com . www.sw-bc.com

Händler / Dealer